

Start by unfastening the 8 screws marked in red using the T10 Torx.

Afterwards, hold the machine together and flip it over.



Gently lift the top off.

The focus is on the bottom left side of the machine, marked in red.

The screen cover marked in yellow can be lifted off for easier access.
(remember to put it back on before the top is mounted again)

